

## 32" Wide Format Laminate

The RSL-820CLS is designed and engineered for single sided cold lamination as well as mounting of display images. Features simple set-up with one button operation. Standard features include a foot pedal for hands-free operation and a stand not found on many other competitive laminators at this width

### Key Benefits

- **User Friendly Controls** and foot pedal for easy one person operation
- **Idler Bars** add tension and help to eliminate wrinkling while laminating
- **Quick Notch** system for gap adjustment and easy webbing
- **Rear Cross Cutter** for removing laminated documents as they exit



The RSC-820CLS is a high quality, economically priced cold laminator specifically designed for users to easily and professionally finish wide format graphics. The compact design makes it ideally suited for graphic shops that have limited space availability. Built for safety and ease of use, this sturdy machine is perfect for laminating and mounting pressure-sensitive graphics up to 32" wide. It has a durable, sturdy frame construction and requires little assembly and minimal maintenance

VERSATILE

USER  
FRIENDLY

RELIABLE



## 32" Wide Format Laminator

### SPECIFICATIONS

MODEL	RSC-820CLS
Maximum Laminating Width	32"
Max Mounting Gap	9/32"
Max Laminating Speed	8.2 ft./min
Speed Control	Yes
Transport Type	2 Rollers
Remote Control	No
Reverse	Yes
Cross Cutter	Yes
Foot Pedal	Yes
Rear Cross Cutter	Yes
Stand Included	Yes
Hot Lamination Capable	No
Cold Lamination Capable	Yes
Heat Assist Roller	No
Nip Adjustment	Quick Notch
Feed Table	Removable
Auto Grip Hubs	3" included
Release Liner Take Up	Yes
Idler Bars	Yes
Unit Weight	188 lbs.
Dimensions (WxDxH)	41" x 21" x 43"
Carton Weight	221 lbs.
Carton Dimensions (WxDxH)	51" x 31" x 24"
Voltage	AC 120V / 60Hz

Included 3" Auto-Grips



User Friendly Controls



*The roller nip adjustment quick-select notch system used on the RSC-820CLS roll laminator significantly simplifies adjusting the gap between rollers, making webbing and mounting easier.*

Your Local Dealer:

