



# SEAL® 65 EL

## COLD LAMINATOR



**COLD**  
ROLL LAMINATOR

**LAMINATES**  
UP TO 65" WIDE

**DURABLE**  
UNIFRAME CONSTRUCTION



## SEAL® 65 EL COLD LAMINATOR

Designed for ease-of-use and minimal maintenance on sturdy uni-frame construction, the 65 EL is ideal for creating professionally-finished wide format graphics. Includes comprehensive safety system with self checking eyes and emergency stops.

*TUV SUD Certified in US/Canada*

### FEATURES:



#### Cold Lamination

Cold roll laminator capable of mounting and laminating pressure-sensitive graphics.



#### Maximum Versatility

Confidently finishes a variety of applications. Laminates graphics up to 65" wide at speeds up to 14'/minute. Manual nip adjustment up to 1" for handling of most substrates. Factory installed image guide and leveling feet help to ensure perfect alignment and flat lamination.



#### Easy to Use

Simplified controls and easy material loading, featuring auto-grip rollers, and flip-up in-feed table for fast webbing, ensure easy and efficient finishing. Auto-grip supply shaft storage kit and factory installed roll trough keep rolled prints in place.

Laminator Type	Cold
Maximum Substrate Width	65" (1651 mm)
Maximum Laminating Speed	14'/min. (4.25 m/min)
Foot Switch	Yes
Film Type	Pressure Sensitive
Core Diameter	3" (76 mm)
Maximum Substrate Thickness (Nip)	1" (25 mm)
Roller Pressure	3 lbs./in. (0.53 N/mm)
Auto-Grip Shafts	2
Maximum Roll Diameter	Unwind 8" (203 mm) Take-Up 6" (152 mm)
Maximum Film Weight	Unwind 85 lbs. (38.5 kg) Take-Up 35 lbs. (15.9 kg)
Electric Requirements	115VAC, 50/60Hz, 1A, 115W-NEMA 5-15 Plug
Machine Dimensions	48"H x 82.3"W x 24"D (1220 mm x 2090 mm x 610 mm)
Machine Weight	430 lbs. (195 kg)
Shipping Dimensions	61"H x 88"W x 30"D (1549 mm x 2235 mm x 762 mm)
Shipping Weight	544 lbs. (247 kg)
Warranty	2 Year Limited. Extended warranty options available

©2024 ACCO Brands. All rights reserved. All other trademarks are the property of their respective owners.



ITEM#	DESCRIPTION
Z65659	SEAL® 65 EL LAMINATOR